


COFFEE BEAN GRINDER

Coffee Bean Grinder Quick Guide

SKU G4B


ENGLISH



This product can be directly adjusted from the outer ring precision, adjust the thicknessof coffee powder.

Maximum powder capacity: 22g

USAGE



GRINDING SETTING

A total of 12 big gear, 55 fine gear.

Coffee Type	Turkish coffee / over 20bar high pressure coffee machine	8~20bar high pressure Italian coffee machine / air pressure pot	Mocha coffee pot / steam pressure coffee pot / air pressure pot	Hand coffee maker / drip coffee maker / siphon pot	Frend press kettle
	Ultrafine	Fine	Medium Fine	Medium Coarse	Coarse
Grind Setting	0~1	1~3	3~5	6~9	9~11

PRECAUTIONS


- In order to protect the sharpness of the core, try not to operate below grade 1.
- The core is sharp, do not remove easily, so as not to cut people.
- Do not grind exceptionally hard objects.
- Keep dry and do not soak in water for a long time.
- Keep away from children.
- Do not exchange parts with other grinder.



Notice

1. First cover the arm handle on the spindle, and then use the spanner to unscrew the lower spindle nut.
2. Do not disassemble the fixing nut on the upper spindle.

中文



本品可以直接从外圈精密调节咖啡粉粗细，无需调零校准，定位精准。

最大装粉量：22g

使用方式



咖啡粉粗细档位选择

共有12个大档位，55个细档位。

适用咖啡类型	土耳其咖啡 / 大于20bar 高压咖啡机	8~20bar高压意式咖啡机 / 气压咖啡壶	摩卡壶 / 蒸汽压力咖啡壶 / 爱乐压 / 气压壶	手冲咖啡壶 / 滴滤咖啡壶 / 虹吸壶	法压壶
粉末粗细度	超细粉	意式细粉	中度细粉	中度粗粉	粗粉
档位	0~1档	1~3档	3~5档	6~9档	9~11档

注意事项

- 为保护磨芯锋利，尽量不要低于1档操作。
- 磨芯锋利，不要輕易拆出，以免割伤人。
- 勿用于碾磨特坚硬物体。
- 保持干燥，勿长期泡水。
- 儿童勿拆。
- 不要与其它磨豆机互换零件。

拆装注意

先将摇臂手柄套在主轴上，再用板手旋开下部的主轴螺母。请勿拆开主轴上部的固定螺母。